



1. Place the shoerack up against the wall and make sure it is leveled.
2. Mark the 6 mounting holes with a pencil and remove the shoerack.
3. Drill the 6 holes at the pencil marks. Use a 10mm drill bit.
4. Insert the wall plugs into the holes.
5. Insert the bolts into the wall plugs.
6. Tighten all bolts equally with a hex key.